

Focus on car navigation for 15 years

Android Car Navigation User Manual

Shixian 9G1G32



Android Car Navigation User Manual

Shixian 9G1G32

System	Android 11.0
CPU	Spreadtrum UIS8141E,4-core ARM Coretex™-A7, 1.3GHz
GPU	Single-core ARM Mali-T820,up to 600MHZ
RAM/ROM	1+32GB
Screen resolution	1280*720
Radio	Four in one
WIFI	Four in one
GPS	Built-in GPS navigation system, GPS/BDS
Bluetooth	Built-in BT4.0,Bluetooth music, phonebook, hands free
EQ mode	JAZZ,Pop,Classical,Rock,News,Urban,Techno
Image format	JPG/PNG/JEPG/Bmp
Audio format	MP3/ACC/FLAC/WAV/M4A/MP2/ARM/OGG/...
Video format	MP4/3GP/AVI/DVIX/FLV/MKV/...
Audio input	One way of AUX AUDIO
Audio output	2.0CH
Video input	AUX/reverse rear view
Video output	supported by plug-in 7026 module
USB	two way
Language	Persian, English, Arabic etc
Extended functions	OBD,DVR,ADAS,Vioce...
Operation temperature	-30°C ~ 75°C
Storage temperature	-40°C ~ 85°C

Android Car Navigation User Manual

Shixian 9G1G32








The use of certain features of these devices depends on networking service provider's network settings and performance. In addition, due to the different network service providers.

1. Quick Review Warning: Before using this device, please read the manual safety and law information.

1.1 Turning On and Turning off

Turning on	When you plug in the car keys, switch On ACC START Or the car's ACC power, the device will be automatically turned on, displaying the boot animation LOGO.
Turning off	When you take off the key, switch to ACC OFF, or turn off the car's ACC power, the device will automatically be shut down.

1.2 Panel Function Button

Picture	Button	Function
	Microphone	this is the voice when click the panel button
	Reset Button	Click reset button to reset system and re-start.
	Power	In the off state, press this button short, the system is turned on.
	Main Interface	Click to enter into main interface.
	Back Click	to back to the last interface.
	Voice high	Turn this button, the volume is increased
	Voice low	Turn this button, the volume is decreased.

Remark: All long press means press time at least lasting 3seconds; Button and socket is different according to different car types, please take real type as standard.

Android Car Navigation User Manual

Shixian 9G1G32

1.3 Tips for Using Touch Screen

When using the touch screen, you can use several ways to perform corresponding operations on the device.

1.3.1 Clicking Function

You could select an application icon or option on the screen to realize clicking function. For example, click Bluetooth to enter into Bluetooth application.

1.3.2 Pressing Function You could press the current user interface, icon inputting column by pressing function. For example press on the blank area of the main interface, then comes a pop.up menu, you could perform some function

1.3.3 on the menu. Dragging Function Drag the touch screen or press the scroll bar for up and down operation. For example, browse the contact list of the Bluetooth phones by dragging function.

1.3.4 Zooming Function When browsing the web, click the screen twice. then you could zoom in or out the page content. Or you could press the screen with two fingers by control the sliding distance between the fingers to zoom in or out the page content.


Android Car Navigation User Manual

Shixian 9G1G32

1.4 Main Screen You can use the touch screen operation to use the various functions of the device. This equipment has a total of five main screen, left or right sliding can be switched with each other. Any interface press the HOME physical buttons on the panel to return to the main screen interface, and display the application icon in the main screen interface, click any application icon to open the program.



Note: You can add the freedom of the space of the main screen or Remove Programs icon to see equipment Basic Settings section. Click the application icon; you can view all of the programs of the equipment.



1.5 Status bar indicator Icons on the left top of the screen are notifications for messages and events; icons on the right top of the screen are device status indicator..If there is new message, it will be displayed on the status bar, slide your finger gently from the status bar.

Android Car Navigation User Manual

Shixian 9G1G32

Language setting

